

Key Indicator For Yamaha XV1600A Wiring Diagram

1. Generator
2. Rectifier/regulator
3. Main switch
4. Battery
5. Wireharness positive lead
6. Wireharness negative lead
7. Main fuse
8. Starter relay
9. Starter motor
10. Backup fuse
11. Relay unit
12. Fuel pump
13. Throttle position sensor
14. Ignitor unit
15. Ignition coil
16. Spark plug
17. Decompression solenoid
18. Pickup coil
19. Neutral switch lead
20. Neutral switch
21. Speed sensor
22. Meter assembly
23. Engine trouble indicator light
24. Neutral indicator light
25. Speed meter assembly (speed meter, combination meter and fuel level meter)
26. Fuel level indicator light
27. Meter light
28. High beam indicator light
29. Turn signal indicator light
30. Fuel sender
31. Alarm
32. Flasher relay
33. Horn
34. Diode
35. Sidestand switch
36. Left handlebar switch
37. PASS switch
38. Dimmer switch
39. Horn switch
40. Clutch switch
41. Turn signal switch
42. Front flasher light (left)
43. Front flasher light (right)
44. Rear flasher light (left)
45. Rear flasher light (right)
46. Auxilliary light
47. Headlight
48. Rear brake light switch
49. Right handlebar switch
50. Front brake light switch
51. Light switch
52. Engine stop switch
53. Start switch
54. Tail/brake light
55. Signaling system fuse
56. Ignition fuse
57. Headlight fuse
58. Carburettor heater fuse
59. Thermo switch
60. Carburettor heater
61. Carburettor heater ground